

TPV Series Valves


Installation and Operation Guide

Specifications

- Flow range: 0.10 – 40 GPM
- Operating pressure: 10 – 175 PSI
- Encapsulated Solenoid:
 - 24 V a.c., 60 Hz (nominal)
 - 19 V a.c., 60 Hz (minimum)
- Inrush: 0.4 amps, 11.50 VA @ 24 V a.c., 60 Hz
- Holding: 0.2 amps, 5.75 VA @ 24 V a.c., 60 Hz

Friction Loss:

GPM Flow	.10	.25	5	10	15	20	30	40
PSI Loss	2.0	2.0	3.5	3.9	3.0	3.3	7.0	13




TPV Valve Installation Guidelines

- The TPV series valves do not provide backflow prevention. Contact your local municipal authority for specific building codes, permits and backflow prevention measures required for the connection of an underground sprinkler system.
- Note the flow direction arrows on top of the valve bonnet or valve body and install accordingly.
- The valve may be installed at any angle when operating in a clean water system. In effluent water systems, the valve must only be installed with the solenoid in the upright vertical position.
- When installing valves below grade, installation within a valve box is recommended for protection, ease of adjustment and service.
- Installing a manual shut-off valve between the main water supply and automatic valve or valve manifold is recommended for ease of valve maintenance and sprinkler system winterization.

Installation Procedure

Figure 1



1. From the backflow device, route 1" schedule 40 PVC pipe to the valve or valve manifold inlet. Use 1" class 200 PVC on the valve outlet. Valves with a barbed outlet require a 1" or 1.25" polyethylene (poly) pipe secured with a hose clamp.
2. For threaded valve body models, prepare 1" slip/thread PVC pipe adapter fittings with three to four complete wraps of PTFE tape evenly covering the threads. Install adapters to the valve body and tighten securely.

⚠ CAUTION: Use only PTFE tape on threaded valve connections. Pipe dope or similar compounds will damage plastic threads.

3. Flush the supply line thoroughly before installing the valve.
4. Carefully prime and cement PVC pipe to the valve fittings (or directly to valve for slip-fit valve models).


⚠ CAUTION: Apply PVC cement sparingly. Excess cement can pool in the valve body and damage the internal bleed port.

Note: Allow all cemented PVC fittings to cure for approximately one hour before applying water pressure.

5. On barbed outlet valve, slip a stainless steel hose clamp onto the poly pipe. Push the poly pipe onto the barbed fitting covering all barbs. Position the hose clamp over the barb contact area and tighten securely.
6. Route a multi-wire, direct-burial sprinkler cable from the sprinkler timer to the valve location. If the cable run is less than 800', 18-gauge wire is sufficient. For distance from 800' – 2000', 14-gauge wire is recommended.
7. Using wire splice connectors, attach either wire from each valve solenoid to the white cable wire. This wire is designated as the valve common wire. Connect the remaining wire from the solenoid to one of the color-coded cable wires. Ensure all wire connections are secure and waterproof.

⚠ CAUTION: Use grease caps or similar waterproofing method on all wire splice connections to prevent corrosion, connection failure and short circuit.

Figure 2



- At the sprinkler timer, connect the white common wire to the output terminal labeled "C" or "COM." Connect each color-coded valve wire to the numbered output terminals in the order you wish the valves to operate during the automatic watering cycle.
- Open the shut-off valve from the water source. Test valve operation using the timer or manually at the valve.

Manual Operation

Note: The valve can be manually operated using the external or internal bleed controls. Refer to **Figure 3**.

Bleed Screw (external bleed): Turn the Bleed Screw counterclockwise one full turn or until water begins discharging from the port.

Note: Removing the bleed screw is not required for manual operation, but can be removed to help flush debris from the upper diaphragm area.

To close the valve, turn the bleed screw clockwise until it stops.

Do not over-tighten!

Bleed Handle (internal bleed): To open the valve, move the Bleed Handle counterclockwise to the stop. The valve will open as discharge water is routed internally downstream. To close the valve, move the handle clockwise until resistance is felt. Do not over-tighten!

Flow Control Adjustment Handle (for valve model with flow control)

The valve is set for maximum flow at the factory. If flow adjustment is required, use the following procedure:

- While the valve is operating, turn the flow control handle clockwise to decrease flow or counterclockwise to increase flow.

CAUTION: Do not use the flow control to shut off the valve. Do not force the flow control handle beyond the end of normal adjustment travel. Damage to the flow control components may occur. Do not remove the plunger retainer from the solenoid. External leaks between the bleed plug and the solenoid may occur.



Maintenance Procedure

The TPV series valves features a bolted valve cap which enable for easy removal during field service disassembly.

- Shut off the main water supply and bleed pressure from the valve using the external bleed screw.
- Referring to **Figure 4**, unscrew the six bolts that secure the valve nut cap (1) to remove. Remove the cover assembly (2) by gently rocking the flow control handle back and forth until the assembly is loosened. Remove the spring (3), diaphragm (4) and divider (5).
- Inspect, clean and reinstall the parts in the reverse order.

Winterization

When winterizing the sprinkler system using compressed air, operate each valve manually from the timer or at the valve for a minimum of one minute, enabling each valve to be thoroughly drained.



The Toro Promise — Limited Five-Year Warranty

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrants, to the owner, each new piece of equipment (featured in the current catalog at date of installation) against defects in material and workmanship for the period described below, provided they are used for irrigation purposes under manufacturer's recommended specifications. Product failures due to acts of God (i.e., lightning, flooding, etc.) are not covered by this warranty.

Neither Toro nor Toro Warranty Company is liable for failure of products not manufactured by them even though such products may be sold or used in conjunction with Toro products.

During such warranty period, we will repair or replace, at our option, any part found to be defective. Your remedy is limited solely to the replacement or repair of defective parts.

Return the defective part to your local Toro distributor, who may be listed in your telephone directory Yellow Pages under "Irrigation Supplies" or "Sprinkler Systems," or contact The Toro Warranty Company P.O. Box 489, Riverside, California, 92502.

Phone (800) 664-4740 for the location of your nearest Toro distributor or outside the U.S., call (909) 688-9221.

This warranty does not apply where equipment is used, or installation is performed, in any manner contrary to Toro's specifications and instructions, nor where equipment is altered or modified.

Neither Toro nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of equipment, including but not limited to: vegetation loss, the cost of substitute equipment or services required during periods of malfunction or resulting non-use, property damage or personal injury resulting from installer's actions, whether negligent or otherwise.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

All implied warranties, including those of merchantability and fitness for use, are limited to the duration of this express warranty.

Some states do not allow limitations of how long an implied warranty lasts, so the above limitation may not apply to you.

This warranty gives you specific legal rights and you may have other rights which vary from state to state.

The TPV series valves is covered by this warranty for a period of five years from the date of installation.